


Compressed Air Safety



An overview of the general safety requirements and safety precautions for using compressed air in machine shops.

General safety requirements for compressed air

The following precautions pertain to the use of compressed air in machine shops:

1. All pipes, hoses, and fittings must have a rating of the maximum pressure of the compressor. Compressed air pipelines should be identified (psi) as to maximum working pressure.
2. Air supply shutoff valves should be located (as near as possible) at the point-of-operation.
3. Air hoses should be kept free of grease and oil to reduce the possibility of deterioration.
4. Hoses should not be strung across floors or aisles where they are liable to cause personnel to trip and fall. When possible, air supply hoses should be suspended overhead, or otherwise located to afford efficient access and protection against damage.
5. Hose ends must be secured to prevent whipping if an accidental cut or...