





Overhead Shop Crane Safety Infographic



Overhead Crane Hand Signals



MAGNET IS DISCONNECTED



Crane Operator ONLY
Spread both hands apart, palms up.

EMERGENCY STOP



An emergency stop signal must be accepted from any person.

ACRA Enterprises, Inc. 1-800-992-0689 www.acratech.com

Source: <https://www.pngegg.com>