

# Materials Handling – Slinging on Overhead Crane Hooks Fact Sheets



## HOW SHOULD YOU SLING A LOAD ONTO A CRANE HOOK?

- Make sure you have the required training, qualifications, or certification as determined by your jurisdiction to operate the crane.
- Visually inspect the crane before use.
- Determine the weight of the load to be lifted.
- Select the right sling for each job using the manufacturer's tables. A slinger must be familiar with these tables showing the safe capacities of slings. (A slinger or rigger is the person who hooks loads onto cranes using various types of slings.)
- Inspect each item of lifting equipment before and after lifts.
- Tag defective slings and dispose of damaged ones.
- Make clear signals according to standard signals. Refer to Materials Handling – Crane and Hoist Hand Signals for examples.
- Signal the crane operator from only the one slinger who is in charge of lift. The only exception is a stop signal.
- Protect slings from damage by sharp edges with corner saddles, padding, or wooden blocks.
- Warn all people to get out of the load area before starting the lift.
- Protect your hands and fingers: when slack is being taken out of a sling, keep them from between the sling and load so they will not be trapped and crushed. Step away before the lift is made.
- Make sure a load is high enough to clear all objects before signaling for the crane to move.
- Walk ahead of the moving load and warn people to keep clear. Use guide ropes to prevent rotation or other uncontrolled motion.
- Hook unused sling legs to the sling ring.
- Set down loads on blocking – never directly on a sling.
- When not in use, hang slings on racks or store according to manufacturer's directions.

## What should you avoid when slinging a load?

- Do not exceed the capacities of slings, fixtures and cranes.
- Do not twist or tie knots in slings or use bolts, nails or pieces of wire to shorten slings.
- Do not splice together broken slings.
- Do not ride on hooks or loads.

- Do not allow workers to walk or work under a load.
- Do not lift a load over a worker.
- Do not attempt to pull or push loads to a spot that is not under the hoist.
- Do not drag slings. Avoid pulling slings out from under loads by crane.
- Do not leave unused slings, accessories, or blocking lying on the floor.
- Do not carry a load by inserting the point of the hook into a link of the chain.
- Do not hammer a sling into place.
- Do not leave loose materials on a load.
- Do not use slings that are stretched, broken, or defective.
- Do not leave suspended loads unattended.
- Do not expose slings to temperatures beyond the range recommended by the manufacturer.

*Source: © Copyright 1997-2021 CCOHS*