

# Welding – Ergonomics Fact Sheets




## WHAT ARE ERGONOMIC RISK FACTORS ASSOCIATED WITH WELDING?

- Lifting heavy loads (cylinders, cables, etc.).
- Awkward body postures (outreached arms, awkward position of neck and head, kneeling/squatting).
- Static body positioning (long duration of tasks, manual precision).
- Continuous force (grip strength).

## WHAT ARE SOME TIPS FOR A GOOD WORKING POSTURE WHILE WELDING?

- Learn to recognize symptoms of work-related musculoskeletal disorders (WMSDs; also called repetitive strain injuries or RSIs). Repeated uncomfortable postures and tasks can cause injury.
- Avoid awkward body positions which cause fatigue, reduce concentration and lead to poor welds which may need to be repeated.
- Always use your hand to lower your helmet. Do not use a “jerking” motion of your neck and head.
- Position yourself in a stable, comfortable posture.
- Position the welding item as flat as possible, on a horizontal surface, between waist and elbow height.
- Position stool or scaffolding at a comfortable height to allow working in a seated position.
- Avoid working in one position for long periods of time.
- Work with material slightly below elbow level when working in a sitting position.
- Work with material between waist and elbow heights for comfort and precision when working in a standing position.
- Use a foot rest if standing for long periods.
- Always store materials and tools within normal reach.
- Use positioning aids to accommodate work posture.




**Turntable**



**Scissor Lift**


WHAT IS AN EXAMPLE OF A STANDING WORKBENCH DESIGN?

## Standing Workbench Design



WHAT IS AN EXAMPLE OF A SEATED WORKBENCH DESIGN?

## Seated Workbench Designs




Source: Golavatjuk et.al. creation of optimum labour conditions for electric welders with regard to ergonomic requirements. IIW Calloquium on Welding and Health, Lisboa (1980)

WHAT SHOULD I KNOW BEFORE LIFTING CYLINDERS MANUALLY?

- Find out the weight of an object before attempting to lift it.
- DO NOT lift full or partially full cylinders on your own.
- Use a lifting aid if the object is heavy.
- Use a trolley or a mechanical lift to lift or move compressed gas cylinders.
- Get help with heavy or awkward loads if a lifting aid is not available.
- Do a few warm up stretches before lifting.
- Protect hands and feet in case the load falls.
- Place forward foot around the cylinder if it must be lifted manually.
- Lower the cylinder across thigh by pressing down with rear hand while holding cylinder underneath and slightly beyond center point.
- Raise end to desired height.

- Push cylinder forward by rear hand.



#### **WHAT SHOULD I KNOW WHEN MOVING CYLINDERS?**

- Make sure the cylinder cap is secured.
- Tilt the cylinder slightly on its edge and roll it slowly in the direction desired. Move short distances only.
- Use a cylinder trolley for longer distances.
- Place one hand on top of the cap and the other hand on the shoulder of the cylinder.
- Always chain the cylinder to the trolley.

#### **WHAT SHOULD I KNOW ABOUT LIGHTING AND COLOUR?**

##### **Lighting**

- Ensure general lighting is adequate to allow safe access and handling of equipment.
- Use additional task lighting for precision work.
- Avoid excessive glare from light sources or reflections.
- Prevent excessive contrast between the workpiece and background.

##### **Colour**

- Select matte finishes for welding area to avoid reflection of welding arc light, and to obtain a satisfactory level of lighting.
- Choose any colour except blue or turquoise; they reflect UV light.
- Reduce distraction by making piping, ducting or structural supports the same colour as the background, unless piping requires a second colour coding.

*Source: © Copyright 1997-2021 CCOHS*